



CAUTION/DEFECT & DAMAGE

CAUTION:

In case of difficulty in operating:

- Be sure to use new Alkaline batteries.
- Turn intensity control to maximum.
- Remove the cartridge, clean the connector with a cotton swab and re-insert into the head gear, and then turn the unit back on.

Never play when walking, driving or in any situation when your attention is on the game and not on your surroundings.

You have purchased a state of the art optical instrument. Treat it gently for long playing hours. Treat the Visor with special care. Do not scratch it or use abrasive cleaning materials such as paper. Use lens cloth or ordinary tissue paper. If you need to clean oily finger marks, use soapy water or window cleaning solvent.

Your lens is made from polycarbonate which is shatter resistant material. The lens may dislodge itself from the hinges when you drop your R-Zone.

TO STORE YOUR R-ZONE, TURN OFF THE UNIT AND FOLD THE LENS TO THE FOLDED POSITION FOR PROTECTION.

TIGERING.

PATENTS PENDING
ALL RIGHTS RESERVED
71201ITIE-2
PRINTED IN HONG KONG